1. Alignment and Adjustments

1. Tuner



KST-ML011MA0-50S (TOP VIEW)

* Adjustment Location of Tuner PCB

ITEAM	AM(MW) OSC Adjustment	AM(MW) RF Adjustment
Received FREQ.	522~1611 KHz	594 KHz
Adjustment point	MO	MA
Output	1~7.0 V	Maximum Output (Fig1-4)



Fig 1-4 OSC Voltage

FM THD Adjustment	
SSG FREQ.	98 MHz
Adjustment point (FM DET)	FM DETECTOR COIL
Output	60 dB
Minumum Distortion (0.4% below) (Figure 1-1)	



Figure1-1 IF CENTER and THD Adjustment

FM Search Level Adjustment	
SSG FREQ.	98 MHz
Adjustment point (SVR1)	BEACON SENSITIVITY SEMI-VR(20KΩ)
Output	28 dB(±2dB)
Adjust SVR1 so that “TUNED” of FLT is lighted (Figure 1-2)	

*Adjust FM S.S.G level to 28dB



Figure1-2 FM Auto Search Level Adjustment

AM(MW) I.F Adjustment	
SSG FREQ.	450 kHz
Frequency	522 kHz
Adjustment point	AM IF
Maximum output (Figure 1-3)	



Figure1-3 AM I.F Adjustment